





#### **SAFETY WARNINGS & EQUIPMENT INSPECTION**

- Owners and installers please note these safety warnings and make use of this checklist on a regular basis.
- Follow installation instructions when erecting equipment.
- Ground surfaces around equipment should be restored as needed. Concrete footings should never be exposed. Surface depth should comply with ASTM and CPSC specifications.
- Check for and repair damage caused by wear or vandalism, a major factor in injury causing situations.
- All protruding bolts should be covered or cut off and finished smooth. Sharp edges on pipes should be capped or removed. Check for bent, broken, or severely worn pipe, and replace.
- All equipment should be free of rust and repainted whenever necessary to deter rusting.
- We provide our customers with layout sheets and installation instructions. Please keep on file the specifications sheet that contains the listing of every part used.
- Never add components not intended for use with this product.
- Regular maintenance is necessary in this and all park and recreational equipment to insure the safety of the user.
- Note: Proper maintenance of equipment requires regular tightening of all bolts, nuts, and setscrews.
- Note: Regular checking of all parts, castings, etc. should be made. If a part is broken or worn, it should be replaced immediately.
- Check to be sure all fittings are tight and that bars and pipes do not move.
- Replace all worn S-hooks. S-hooks must be completely closed. Failure to close S-hooks can result in serious injury to the user.
  NEVER reuse S-hooks.
- Test for free movement of swing hanger and other moving attached parts.
- Check for worn chains and replace them.
- A soft resilient surface should be placed under all swings extending at least twice the height of the top rail both front and back.

## **HARDWARE**








5/16" Flat Washer




5/16" Kep Nut



#8-32 Nylon Lock Nut



5/16" x 3-1/4" Carriage Bolt



5/16" x 2-1/2"


Carriage Bolt


#0 22 t


#8-32 5/8" Button Bolt




# TOOLS REQUIRED









#### **ULTRA SITE PRODUCT SPECIFICATIONS**

#### 512-SD MULTI TABLE

Tops: Laser cut 12 gauge steel. The understructure/attachment plates are laser cut 7 gauge steel.

Spun Seat: Spun 12 gauge steel. 1/2" diameter holes are laser cut. The understructure/attachment plates are fabricated from 7 gauge x 1-1/2" flat bar. Electrically MIG welded.

Seat: Laser cut 12 gauge steel. 5/8" diameter holes are laser cut. The understructure/attachment plates are fabricated from 7 gauge x 1-1/2" flat bar. Electrically MIG welded.

Coating: Oven fused functionalized polyethylene copolymer-based thermoplastic. Fluidized bed coating application with superior mechanical performance, impact resistance and UV-stability.

Frame: 2-3/8" O.D. x 12 gauge pre-galvanized structural steel tubing. Spreader plate is 10 gauge. Seat and top mounting points are 7 gauge steel. Legs are bent over a mandrel through the bend radius producing a wrinkle free bend. All electrically MIG welded.


Frame Coating: Electrostatic powder coated application oven cured.


Hardware: Stainless steel hardware fasteners.

Dimensions: Tops are 42" x 42". Spun seat is 14-1/2" diameter and rectangular seat is 12" wide x 36" long. Outside to outside dimension is 79-1/2" x 59-3/4" x 42" high.




#### **COMPONENTS**













TOPS.




USING A MINIMUM OF 2 PEOPLE, CAREFULLY FLIP TABLE OVER. ATTACH SUPPORT TUBE TO BOTTOM SIDE OF TOP AND ATTACH BAR HEIGHT LEG TO BOTH TOPS. ATTACH OTHER LEG (ITEM #4) TO TOP.






ATTACH SPUN SEAT TO LEG. ATTACH RECTANGULAR SEAT TO BAR HEIGHT LEGS.






ATTACH SPREADER PLATES BETWEEN ALL (4) LEGS.





ATTACH VERTICAL PANELS BETWEEN TABLE TOPS.







## **OVERALL DIMENSIONS**

